

GLASS & ALL-PURPOSE CLEANER

WE HELP KEEP YOU CLEAN!

Building

Partnerships in Quality, Innovation, and

Environmental Responsibility™

Why it's a better cleaner

- Penetrates and removes dirt, grease, smoke film and other soils quickly.
- Exceptional streak-free shine.
- Multi-tasking—Cleans a variety of surfaces.
- Easy-to-use.
- Safe on most surfaces.
- No acid, ammonia, bleach, or butyl.



How it cleans

GLASS (WINDOWS, DOORS, & DISPLAY CASES):

- Spray on generous amount of cleaner. One entire pane of glass should be washed at a time, starting from the bottom up. Scrub as necessary to remove soils.
- 2. Remove soiled water with squeegee.
- *3.* Wipe excess solution from the window seal and frame.

OTHER SURFACES:

- 1. Apply solution directly to the spot or area to be cleaned.
- 2. Wipe solution and soil from surface with a clean paper or lint-free cloth towel.
- 3. Repeat as necessary.



For general cleaning, ready-to-use GLASS & ALL-PURPOSE CLEANER is in its own dispenser bottle. Attach trigger device, adjust the nozzle, and spray.

Where it cleans

- Windows
- Refrigerator Fronts
- Mirrors
- Door Knobs
- Glazed Tile
- Leather Upholstery
- Porcelain
- Plastic Upholstery
- Stainless Steel
- l Vinyl and Other
- Chrome
- Hard Surfaces
- Stovetops
- Salad Bar Guards
- Counter Tops •
- Display Cases

Technical Data

Appearance	Clear Liquid
Color	Blue
Odor	Mild Perfume
Flashpoint	> 140° F
Free-wiping	Yes
% Phosphates	None
ρH	~10.4 @ 100%

04/20